


品名：110Wソケット取付脚
 適用：TH3,4,5,6(A),15,16(A),17,18A



記号 \ 型式	TH3,4	TH5,6(A),15 16(A),17,18A
A(板厚)	1.0	1.0
B	45	49
C	34	38
D	6	6
E	20	30
F	2	2
G	9	9
H	4.3	4.4
I	30	30
J	52	46.5
K	46.8	38.5
L	7	7.3

